

Thank you for your purchase of the  
IPC Eagle Battery Powered Smartvac Vacuum Sweeper  
To keep your Vacuum Sweeper operating at peak service  
We recommend the following Daily / Weekly  
Maintenance Steps:



1. Daily- Transport Smartvac to area where rear debris hopper is to be emptied
2. Daily- Turn Power to off position
3. Daily-Remove Rear Debris Hopper and place debris in trash receptacle
4. Daily-Inspect both Pre-Filter and Larger Filter to insure they are free of loose debris  
( Take Both Filters off of SmartVac once per week and clear debris using either blown air method by shake out filter in an outside area)
5. Daily- Replace Rear Debris Hopper in proper position on SmartVac
6. Weekly-Remove Top Cover of SmartVac utilizing provided Allen wrench
7. Weekly-Inspect interior compartment of SmartVac to insure there is no loose debris and to insure all cables and electrical connections or in proper order
8. Weekly-Replace Top Cover of SmartVac insuring that Allen screws replaced to secure cover
9. Daily- Inspect Side Broom to insure that it is free of debris and not in a position to misshape Side Broom (Side Broom will automatically raise when in off position.)
- 10.Daily- Inspect larger Center Broom to insure that it is free of loose debris ( once per month remove both Side and Center Broom to insure both are in proper working order and free of loose debris. No tools necessary)
11. Daily– End of Shift-Utilizing provided electrical cable, plug female end of cable into proper Charger outlet on rear of SmartVac
12. Daily– Plug Male end of Electrical cable into near Electrical Outlet to insure proper charging of battery for next day's/ shift



Please call IPC Eagle Technical Support at 800.486.2775 or your  
local Service Company at \_\_\_\_\_